



- 0423 715 901
 - 59 Luke Street Hemmant Qld 4174
- sales@strongcast.com.au


Appendix A.


Ball Valve Installation Instructions


For Valves: ZC9746, QC9746, NC9746, C9745, QC7094, ZC7094, NC7094, NC7095, C2532, QC7095, ZC7095, C7093.





















- 0423 715 901
- 59 Luke Street Hemmant Qld 4174
- sales@strongcast.com.au


Appendix B


Dual Check Valves Installation Instructions


For Dual Check Valves: ZC707920, QC707920, C707820, ZC707925, QC707925, C707825















(For connections to PE pipe, please refer to Appendix D.)


(note 4* AS4020:2018 approved thread tape / sealants only)


Appendix C


Maintenance of Dual Check Valves


For Dual Check Valves: ZC707920, QC707920, C707820, ZC707925, QC707925, C707825













- 0423 715 901
 - 59 Luke Street Hemmant Qld 4174
- sales@strongcast.com.au

Appendix D.

Mechanical Compression Unions for Polyethylene Pipe

Valves: QC7094, ZC7094, NC7094, NC7095, QC7095, ZC7095, C2532, C7093. Fittings:ZC7079, QC7079, C7078, PS4000. Dual Check Valves: ZC707925, QC707925, C707825 Meter Housing

